

# Protection Box - PB11

## Description:

Charged capacitors is a major problem for LCR-meters when used directly on a production line. When capacitors are charged to more than approximately 1uF at 1000V, the DB230 series LCR meters will take damage. The damage of the measuring circuits will depend on the magnitude of this charge.

This damage of LCR meters can be avoided by inserting the PB 11 between the measuring station of the capacitors and the LCR meter.

The PB11 contains spark tubes that will discharge the capacitor without causing damage to the LCR meter.



## Specifications:

Dimensions	H: 3 cm, W: 10 cm, D: 7,5 cm
Weight	0,2 Kg

# simac



Connections	4 terminal axial cable to the DB232/3/6 & CT30
Asseccories	None